

The power behind competitiveness

Delta InfraSuite RowCool

Precision Cooling
Chilled Water Type (HCH1850/ HCH1870)

User Manual

Save This Manual

This manual contains important instructions and warnings that you should follow during the installation, operation, storage and maintenance of this product. Failure to heed these instructions and warnings will void the warranty.

Copyright © 2017 by Delta Electronics Inc. All Rights Reserved. All rights of this User Manual ("Manual"), including but not limited to the contents, information, and figures are solely owned and reserved by Delta Electronics Inc. ("Delta"). The Manual can only be applied to the operation or the use of this product. Any disposition, duplication, dissemination, reproduction, modification, translation, extraction, or usage of this Manual in whole or in part is prohibited without the prior written permission of Delta. Given that Delta will continuously improve and develop the product, changes may be made to the information in this Manual at any time without obligation to notify any person of such revision or changes. Delta will make all possible efforts to secure the accuracy and the integrity of this Manual. Delta disclaims any kinds or forms of warranty, guarantee, or undertaking, either expressly or implicitly, including but not limited to the completeness, faultlessness, accuracy, non-infringement, merchantability or fitness for a particular purpose of the Manual.

Table of Contents

Chapter 1 : Guide for Safe Operation -----	1
1.1 Safety Instructions -----	1
1.2 Installation Instructions -----	1
1.3 Instructions for Use -----	1
1.4 Glossary of Symbols -----	2
Chapter 2 : Introduction -----	3
2.1 Product Introduction -----	3
2.2 Functions and Features -----	3
2.3 Packing List -----	5
2.4 Optional Accessories -----	6
2.5 Appearance -----	6
2.6 Components Identification -----	7
2.7 Piping System -----	9
2.8 Control Panel -----	10
Chapter 3 : Installation -----	11
3.1 Installation Site -----	11
3.2 Space Reservation -----	12
3.3 Handling -----	12
3.4 Positioning -----	13
3.5 Removal of Side Panels -----	15
3.6 Hole Drilling -----	16
3.7 External Piping -----	17
3.8 Power Connection -----	18
3.8.1 Power -----	18
3.8.2 Condensed water pipe -----	23
3.8.3 Control box -----	24
Chapter 4 : Initial Startup -----	27
4.1 Pre Start-up Inspection -----	27
4.2 Power Supply -----	28
4.3 Operating Temperature and Humidity -----	28
4.4 Air Exhaust -----	30

4.5	Water Leakage Detector-----	31
4.6	Water Balance -----	31
4.7	PID Setting-----	33
Chapter 5 : Operation -----		35
5.1	LCD Display Hierarchy-----	35
5.2	Control Panel Operation-----	36
5.3	Status Screen and Main Menu-----	36
5.4	Account Authority and Login-----	37
5.5	Operation Modes -----	38
5.6	Shutdown-----	39
5.7	Setting of Cooling Unit -----	40
5.7.1	Local setting-----	40
5.7.2	Set point-----	42
5.7.3	Controller setting-----	42
5.7.4	Setting of automatic control mode-----	43
5.7.5	Alarm setting-----	44
5.7.6	Inquiry of system status-----	46
5.7.7	Inquiry/ elimination of event log -----	46
5.7.8	Inquiry / reset of running hours-----	47
5.7.9	Change of system type-----	48
5.7.10	Restoration of defaults-----	48
Chapter 6 : Maintenance and Cleaning -----		49
6.1	Firmware Upgrade -----	49
6.2	Storage -----	49
Chapter 7 : Troubleshooting -----		50
Appendix 1 : Technical Specifications -----		55
Appendix 2 : Periodic Inspection/ Maintenance List -----		56
Appendix 3 : Glycol Correction Table -----		58
Appendix 4 : Warranty -----		59

Chapter 1 : Guide for Safe Operation

1.1 Safety Instructions

- Please carefully read all chapters of the Manual before any installation, operation, and maintenance. To avoid personal injury and equipment damage, please be sure to operate the product in accordance with the instructions in this Manual and the markings on the cabinet.
- The unit should only be moved by at least two people so as to guarantee safety.
- In handling or removal of the equipment, please pay attention to its height and center of gravity. When using a transportation tool for handling, it must be raised from the bottom to avoid toppling.
- The unit contains moving components. Be careful to keep it away from your arms, legs, hair, clothes or jewelry so as to avoid any danger.



1.2 Installation Instructions

- The unit can be connected with a single or dual power source. Make sure the input power is disconnected before making a connection. If necessary, use a multi-meter to confirm this.
- Do not install the equipment on a flammable or unstable floor.
- This unit is only intended for indoor use. The indoor environment must be separated from the outside air so as to avoid temperature and humidity interference. Consult the national or local regulations for separating the installation environment.
- The diameters and lengths of all electronic connection wires must follow the requirements of the International IEC or relevant national regulations, whichever is stricter. Meanwhile, the grounding wires of the unit must be effectively connected with the grounding system.

1.3 Instructions for Use

- The inner high voltage of the unit may be fatal! The inner components may have hidden dangers and only qualified service personnel can operate the unit. Improper operation may lead to serious injury or death or equipment damage. Be sure to follow all the instructions and warnings contained in the Manual.
- When replacing the side panels or front or back doors, make sure there is no foreign matter in the cabinet.

1.4 Glossary of Symbols

No.	Symbol	Meaning
1		Indicates supplementary information.
2		Indicates important information that must be heeded.

Chapter 2 : Introduction

2.1 Product Introduction

The Delta InfraSuite RowCool Precision Cooling Unit (Chilled Water Type) adopts a parallel cabinet design and can be set in an area adjacent to a heat load. Its high cooling efficiency can create an effect of dropping temperature. The modularized design facilitates expansion or movement and can be flexibly integrated into your data center environment. With enlargement of your data centers, increased cooling needs can be met by easy re-configuration or addition of the equipment.

When installed in a data center, the untreated air will be sucked in from the rear of the cooling unit and the air, after treatment, will be released from the front of the unit to achieve the aim of cooling.

You can manage your cooling unit via a user-friendly interface. The cooling efficiency can be actively controlled by its built-in MCU and it will remind you of any abnormality via the alarm system so as to guarantee normal operation.

2.2 Functions and Features

- **Intelligent temperature control**

Built-in MCU accurately detects and manages the data center's temperature, automatically adjusts the unit's output, and supports two kinds of automatic control modes, intelligent control mode (default) & PID control mode.

- **User-friendly control interface**

Easy setting and monitoring and access to system status.

- **Automatic spring-resetting of three-way ball valve**

In abnormal power interruption, the inner flow-rate actuator will automatically close the three-way ball valve within 15 seconds to stop chilled water from continuously flowing into the coil and generating condensed water, which may lead to water leakage.

- **Elastic Piping**

Supports upper or lower piping to enable a flexible piping configuration.

- **Alarm system**

Detection of abnormality and reminding the user via a buzzer or an external dry contact device.

- **Detection of heat load temperature**

Accurate monitor of the heat load temperature by remote temperature sensors.

- **Leakage detection**

Optional maximum 50m water leakage detector (4m is provided as default), which will immediately inform the user of any water leakage so as to protect the safety of the equipment.

- **Output and input dry contacts**

Two output and two input dry contacts for fire alarm, smoke alarm, system alarm, etc.

- **Heat insulation side panels**

Isolate the interference of outside temperature.

- **Hot-swappable & multi-speed fans**

The unit equips with high efficiency & energy saving fans, whose rotation speed could be adjustable between 30~100%, and works normally when you change or replace the fans.

- **Lockable front and rear doors and side panels**

Prevent any unauthorized operation.

- **Condensed water pump (optional)**

The condensed water pump and the water level sensor at the bottom of the cabinet automatically drain the condensed water and detect the water level of the condensed water pan respectively to avoid leakage.


- **Casters**

For convenient movement or relocation.

- **Compatible SNMP card (optional)**

Monitoring management through SNMP protocol.

2.3 Packing List



No.	Description	Quantity
①	Delta InfraSuite RowCool Precision Cooling Unit	1
②	User manual	1
③	Key (shared by front & rear doors and side panels)	2
④	Cable Tie	3
⑤	Remote temperature sensor (2.9m)	2
⑥	4-pin terminal block	2
⑦	3-pin terminal block	1
⑧	2.8 mm Hex wrench	1
⑨	Cable gland	2
⑩	Cover plate for communication wiring duct	2
⑪	Cover plate for power supply	1
⑫	Non-woven filter*	1

*Use only for dustproof at trial operation by engineering personnel. Do not continue to use in normal operation.


2.4 Optional Accessories

For purchase of the following optional accessories, please contact service personnel.

- SNMP card: Use the Delta SNMP card to achieve the best compatibility.
- Filters:

	HCH1850	HCH1870
MERV	MERV1	MERV8
Material	Aluminum Washable	Paper Disposable


2.5 Appearance




(Figure 2-1 : Appearance and dimensions)

2.6 Components Identification

External




(Figure 2-2: Front view)



(Figure 2-3: Bottom view)

No.	Description	No.	Description
①	Wiring access	⑨	Lower inlet hole
②	Upper outlet hole	⑩	Lower outlet hole
③	Upper inlet hole	⑪	Casters
④	Input power terminal block	⑫	Levelers
⑤	Removable rear door	⑬	Gradienter
⑥	Removable heat-insulating side panel	⑭	Front door lock
⑦	Side panel lock	⑮	Front door
⑧	Side panel latch	⑯	Control panel

Internal




(Figure 2-4 : Internal components)

No.	Description	No.	Description
①	Upper outlet connector	⑨	Lower outlet connector
②	Upper inlet connector	⑩	Lower inlet connector
③	Upper inlet shut-off valve	⑪	Condensed water pan
④	Manual exhaust valve of outlet water pipe	⑫	Coils
⑤	Filters	⑬	Flow meter
⑥	Three-way ball valve and actuator	⑭	Fans
⑦	Bypass valve	⑮	Power supply unit (each of front side and rear side has one)
⑧	Lower inlet shut-off valve	⑯	Level switch

* Each of the ① ② ⑨ ⑩ connectors is a 1" PT female connector.


2.7 Piping System



(Figure 2-5 : Pipe circuit diagram)

No.	Description	No.	Description
①	Upper inlet connector	⑨	Lower inlet shut-off valve
②	Upper outlet connector	⑩	Lower outlet connector
③	Three-way ball valve and actuator	⑪	Lower inlet connector
④	Flow meter	⑫	Condensed water drain pipe
⑤	Bypass valve	⑬	Condensed water pump (Optional)
⑥	Upper inlet shut-off valve	⑭	Condensed water pan
⑦	Inlet water temperature sensor	⑮	Coils
⑧	Outlet water temperature sensor		

2.8 Control Panel



(Figure 2-6 : Control panel)

No.	Item	Description
①	E.P.O.	Emergency power off button.
②	MAIN ON	The green light indicates power-on. The flashing indicator indicates the unit is in installation mode.
③	STANDBY	The yellow light indicates the unit runs in standby mode. The flashing indicator indicates the unit runs in force mode.
④	WARNING	The yellow light indicates alarm information.
⑤	FAULT	The red light indicates fault information.
⑥	▲ / ▼	Goes back to previous screen or goes to next screen/ Moves up or down/ Increases or decrease number.
⑦	ESC	Goes back to previous screen or cancels current operation.
⑧	↵	Enters your selected item or confirms your selection or setting.



NOTE: The emergency power off button (E.P.O.) is OFF by default. If such a function is needed, please contact service personnel.

Chapter 3 : Installation



WARNING:

1. Only service personnel can perform the following installation procedures. No installation, piping or handling should be performed without authorization so as to avoid equipment damage and personal injury.
2. The high voltage in the equipment is potentially fatal! The inner components have potential dangers and only qualified service personnel can perform wiring.

3.1 Installation Site

When planning the installation site for the cooling unit, you must take the following into consideration so as to guarantee the best efficiency.

- Environmental requirements: The installation site must allow the equipment to move in and out, the flooring must bear the weight of the equipment and there is a sufficient space for maintenance, operation, and pipe repair. The cooling unit can only be located indoors and the indoor environment must be isolated from the outside air to avoid temperature and humidity interference. The outside humidity entry must be minimized in accordance with the local or national regulations so as to avoid the increase of operation costs due to loss of cooling capacity.
- Humidity and heat source: Implement water-proof and heat insulation engineering for the indoor environment so as to isolate the outside humid hot air.



NOTE:


The unit cannot humidify or automatically de-humidify. If the humidity of the installation environment exceeds the operation scope (refer to **4.3 Operating Temperature and Humidity**), the condensation of the water of the coil may lead to a rise in the water level of the condensed water pan, triggering an alarm.

- Noise impact: At a high load, the operation of this cooling unit may produce loud noise. Therefore, it is not suitable to install the unit close to offices.
- Input power: In connecting the power supply, make sure that the power conforms to the rated value and the power distribution device is sufficient to satisfy the load requirement. Inspect the rated values of each unit and make sure they have been properly grounded. One branch circuit or power distribution device can only be connected with one cooling unit.

3.2 Space Reservation

In order to facilitate maintenance, operation, and air circulation, please reserve a net space around the equipment.

It is suggested to preserve 1200mm for the front passage, 600mm for the rear passage and at least 300mm above the cabinet for pipe installation. If the pipeline adopts a lower connection mode, the height of the raised floor should not be lower than 300mm. If the pipeline adopts an upper connection mode, the equipment can be set on a common floor.



(Figure 3-1 : Space reservation)

3.3 Handling

- **Handling Instructions**

Before moving the equipment to the installation site, plan the route according to the following instructions:

1. Make sure the passage, floor, elevator or slope on the handling route can bear the weight of the equipment and handling device, and there is a sufficient net space to avoid collisions.
2. In the case of a slope on the handling route, its inclination must not be greater than 15 degrees so as to avoid toppling the cabinet.
3. The bottom casters are only suitable for short distance movement. For long distance movement, use a handling device (such as **Figure 3-2**) so as to avoid damage to the casters.
4. The casters are only suitable for moving on flat surfaces. Avoid heavy falling of and moving of the unit on uneven ground, which may damage the casters or even result in toppling.
5. When moving the unit, pay attention to its height and center of gravity. At least two people working together should handle the unit so as to guarantee safety.



(Figure 3-2 : Forklift handling)

- **Levelers**

After moving the unit into place, use a wrench to rotate clockwise the four levelers be-side the casters to put them down and stable on the floor. Make sure the unit cannot slide or topple.



WARNING:

The levelers are only used for leveling the unit and cannot be used to compensate for the height difference of the floor so as to avoid toppling.



(Figure 3-3: Leveling feet)


3.4 Positioning

After moving the unit into place and it is parallel with the adjacent cabinet, you must position it so as to ensure its stability. The following two methods can be used, depending on the installation environment:

- **Cabinet fasteners**


If the adjacent cabinets are Delta cabinets (MSR1110 and MSR2110), you may use connecting fasteners to fix the equipment. Each cooling unit is provided with four connecting fasteners (two at the front and two at the rear). You must remove the front and back doors before making the fastener connection. Refer to the following procedures:

- ① If the front door is locked, use the attached key to open it.
- ② Remove the control panel's flat cable and ground wire ①, raise the front door ②, and take it out.



(Figure 3-4: Open the front door)

- 3 Use a screw driver to remove the two screws and ground wire from the rear door ①, lean the rear door and lift it up ② to take it out.




(Figure 3-5: Remove the rear door)



NOTE: Put the front and rear doors that have been removed in a safe place so as to avoid any equipment damage or personal injury due to collisions.

- 4 Use a screwdriver to loosen the screw below the fastener and lock it on the adjacent cabinet.




(Figure 3-6: Join the cooling unit and the adjacent cabinet together)

- 5 Fix the front and rear (8 in all) fasteners with the adjacent cabinet.
- 6 After fixing the fasteners, please re-install the front and rear doors.

- **L-type balance support**

The L-type balance support is originally used to fix the cooling unit on the pallet during transportation and can be used for ground fixing after positioning to provide extra locking force.


- ① Use two M6 screws to fix the L-type balance support below the front door (with the extruding part forward) as shown in **Figure 3-7 ①**.
- ② Use expansion screws to fix the extruding end on the floor. Please see **Figure 3-7 ②**.



(Figure 3-7 : Installation of L-type balance support)

3.5 Removal of Side Panels

If each side panel is locked, use the attached key to open it. There are two door holders on each of the two sides of the side panel. Press them downward at the same time and take out the side panel.




(Figure 3-8 : Removal of side panel)

To re-install the side panel, align the two lower holes and press down the two door holders at the same time to reset the side panel.


3.6 Hole Drilling

Drill holes in the raised floor or ceiling according to the piping mode (upper or lower) as shown in the following figures for pipe passing.

The pipeline is wrapped with an external heat insulation layer to reduce the interference of outside temperature and avoid condensed water. The hole diameter should be about 13mm.



(Figure 3-9: Upper and lower piping positions and dimensions)




(Bottom view)

(Top view)

(Figure 3-10 : Hole diameters and positions for upper and lower piping)

	A	B	C	D	E	F	G
HCH1850	235	192	283	192	120	215	315
HCH1870	223	181	329	293	95	215	315

3.7 External Piping



(Figure 3-11 : Suggested external piping)

No.	Description	No.	Description
①	Automatic exhaust valve	⑤	Y-type filter
②	Thermometer	⑥	Shut-off valve
③	Ball valve	⑦	Balance valve
④	Pressure meter		

Configure an external pipeline and an automatic exhaust valve ① at the water inlet end as shown in Figure 3-9 for removing the air in the pipeline. Set a Y-type filter ⑤ in the water inlet pipe to filter out the impurities and chemical substances in the water. Install a ball valve ③ in front of or behind the Y-type filter to set up a branch circuit. When the filter needs cleaning or maintenance, close the ball valve to let the chilled water go to the cooling unit via the branch so as to avoid shut-off loss. Install a pressure meter ④ in front of and after the Y-type filter and judge if there is a blockage according to the pressure difference.

Configure a multiple functional balance valve ⑦ at the return water end for adjusting the return water flow rate.

- **Pipeline washing**

To guarantee cooling efficiency, you must purify the pipeline to filter out impurities and chemical substances. For pipeline washing, use a hose to create a short circuit to make the chilled water go directly from the inlet end to the return end without passing through the cooling unit. Use a fine-meshed filter (20-mesh suggested) in the Y-type filter to filter out the fine impurities and after 12h~24h water circulation in the pipeline, change a larger-meshed filter (3-mesh suggested).

If you use ethylene as the substance for the chilled water, please refer to **Appendix 3: Glycol Correction Table** for information about cooling capacity and water-side pressure drop.

3.8 Power Connection



NOTE:

1. The input power must conform to the rated value on the equipment nameplate.
2. The diameters of the power wires and backup connecting wires should conform to national or local regulations. The recommend power cord: PVC wiring, H05VV-F, core 3G and 12AWG (2.5mm²).
3. The cooling unit's maximum power consumption is HCH1850: 1000W or HCH1870: 2400W. Please install an appropriate UL-listed or European equivalent breaker in front of the input side of the unit to protect other equipment connected in the same circuit when an overload or short issue occurs.

The suggestion of the breaker is as follows.

HCH1850: Above 300Vac, 8A, 2-Pole

HCH1870: Above 300Vac, 20A, 2-Pole


4. In locking the screws for wiring at the power terminal block, use the recommended installation torque (12.2Kgf-cm).
5. If there is no wire passing through the communication wire duct at the top of the cabinet, cover the duct with the cover plate provided in the accessory package so as to avoid dust accumulation.
6. The length of the conductor between the cord anchorage and the terminals shall be such that the current-carrying conductors become taut before the earthing conductor if the cord slips out of the cord anchorage.

3.8.1 Power


- Dual input



- 1 Pull up the knob ❶ and remove the power supply's cover plate ❷ at the rear of the cabinet top.




(Figure 3-12A: HCH1850: Removal of the power supply's cover plate)




(Figure 3-12B : HCH1870: Removal of the power supply's cover plate)

- 2** Use nippers to remove the cover plate's knocking pieces **1**, take out the two cable glands from the accessory package, remove the cable glands' nuts **2**, use the nuts to fix the cable glands on the cover plate, and pass the power wires through the cable glands **3**.




(Figure 3-13 : Insertion of power wires)

- 3 Use a screwdriver to loosen the screws of the wiring terminal block and use ring-type terminals to secure L1 (line), L2 (line), N1 (neutral), N2 (neutral), and G (ground) wires into the terminal block and lock them.



(Figure 3-14 : Installation of power wires)


- 4 Re-install the power supply's cover plate and rotate the cable glands tightly.




(Figure 3-15 : Re-install the power supply's cover plate)

- **Single input**

- 1 Pull up the knob ① and remove the power supply's cover plate ② at the rear of the cabinet top.




(Figure 3-16A: HCH1850: Removal of the power supply's cover plate)




(Figure 3-16B : HCH1870: Removal of the power supply's cover plate)

- 2 Use nippers to remove the cover plate's knocking piece ❶, take out the one cable gland from the accessory package, remove the cable gland's nut ❷, use the nut to fix the cable gland on the cover plate, and pass the power wires through the cable gland ❸.




(Figure 3-17 : Insertion of power wires)

- 3 Use a screwdriver to loosen the screws of the wiring terminal block and use ring-type terminals to secure L1 (line), N1 (neutral) and G (ground) wires into the terminal block and lock them. Since it is single input, each power supply unit should be each other's backup power. Thus, please use another L1 (line) wire to connect L1 and L2 terminals and use another N1 (neutral) wire to connect N1 and N2 terminals.



(Figure 3-18 : Installation of power wires)

- 4 Re-install the power supply's cover plate and rotate the cable gland tightly.




(Figure 3-19 : Re-install the power supply's cover plate)

3.8.2 Condensed water pipe

The condensed water pipe has been connected in the lower part of the cabinet at one end, and you must pass the other end through the reserved hole at the bottom to drain the condensed water.


Meanwhile, the unit is provided with an optional condensed water pump and the upper or lower piping may be selected. If the upper piping is adopted, the height of the condensed water pipe should not be higher than 5m of the vertical lift of the condensed water pump.




(Figure 3-20 : Installation of the condensed water pipe)


3.8.3 Control box

- Front




(Figure 3-21 : Front of control box)

No.	Item	Description
①	SNMP card slot	<p>This unit is compatible with an SNMP card (optional) and can be connected with a workstation so as to monitor and manage the system based on the SNMP protocol. To install the SNMP card, first remove the dust cover from the control box, use an RJ45 cable (purchase separately) to connect the workstation and the SNMP card. For SNMP card operation and setting, refer to its user manual.</p> <p> NOTE: Please use the Delta SNMP card (optional) to achieve the best efficiency and compatibility. Please contact your local dealer or customer service for more information.</p>
②	RS232, RS485	The RS232 or RS485 port allows you to connect a workstation or power distribution device based on Modbus protocol for remote use.
③	CAN-Link IN/OUT	It is reserved for series connection of several cooling units. It adopts one-Input one-Output mode.
④ / ⑤	Input dry contacts	<p>Normally open, for connecting the fire alarm or smoke detector. When an event occurs, the dry contact device is triggered to form a short circuit. The system will record it in the event log , start the buzzer and light the FAULT indicator.</p> <p>Port ④ : Fire alarm Port ⑤ : Smoke detector</p>


No.	Item	Description
⑥ / ⑦	Output dry contacts	<p>Connect two dry contact output devices and trigger the contacts at specific events.</p> <p>Port ⑥ (System alarm event): Normally open. Connect the dry contact device to this port and the device will be triggered when an alarm event occurs (close the circuit). You may set the triggering conditions. Refer to 5.7.1 Local setting.</p> <p>Port ⑦ (Start of cooling unit) Normally open. Automatically trigger to form a short circuit at the start of the cooling unit to remind the chiller to output chilled water and turn to the normally open status until the cooling unit is powered off.</p>
⑧	Remote temperature sensor ports	<p>At most, three remote temperature sensors (two are provided) can be connected. Qualified service personnel will connect and locate them for you in installation for accurate detection of the temperature of heat loads.</p> <p> NOTE: Without permission, do not relocate the remote temperature sensors.</p>
⑨	Remote temperature and humidity sensor port	<p>Connects the remote temperature-humidity sensor (purchase separately) for accurate detection of the temperature and humidity of heat loads. It is suggested that qualified service personnel perform installation.</p>

- **Rear**

The interfaces at the rear of the control box have been connected at delivery. The connecting components are shown in the table below.



(Figure 3-22A : HCH1850 Rear of control box)



(Figure 3-22B : HCH1870 Rear of control box)

No.	Connects to	No.	Connects to
①	Power automatic transfer relay	⑧	Water level detector
②	Three-way ball valve actuator	⑨	Flow meter
③	EPO device	⑩	Outlet water temperature sensor
④	Fans 1-8	⑪	Inlet water temperature sensor
⑤	Input power (54Vdc)	⑫	Temperature and humidity sensor 1/ 2
⑥	Pressure difference switch (detects whether filters are clogged)	⑬	Input power of control box (24Vac)
⑦	Water leakage detector	⑭	Control panel

Chapter 4 : Initial Startup

4.1 Pre Start-up Inspection



WARNING:

1. Only qualified service personnel can carry out the installation procedures in this chapter.
2. The inner high voltage of this unit is potentially fatal! Make sure the input power has been disconnected before the following actions.
3. A startup without correctly completing **4.1 Pre Start-up Inspection** may lead to serious personal injury or equipment damage!

Please complete all the following inspections before implementing the initial startup procedures.

Inspection List

- **General items**

- ☐ The unit has no external damage.
- ☐ The unit is stably fixed and close to the adjacent cabinet.
- ☐ All the installation procedures have been performed in accordance with the instructions in **Chapter 3: Installation**.
- ☐ The pipes in and outside the cabinet have been correctly connected and the thermal insulating layer of the pipes are free of damage and leakage.
- ☐ The front and back doors have been reinstalled and the flat cable of the control panel has been connected.

- **Environment**

- ☐ The inner environment is an enclosed space and isolated from interference from outside temperature and humidity.
- ☐ The reserved space around the cabinet conforms to the regulation (See 3.2 Space Reservation).

- **Electronic connection**

- ☐ The rated value of the input power conforms to that marked on the nameplate.
- ☐ The equipment has been properly grounded.
- ☐ All electronic connections are tight and stable.

___ The remote temperature (humidity) sensors have been correctly connected and located properly.

___ The water leakage detector has been correctly laid.

- **Mechanical connection**


___ The pipes and valves are free of breaks or damage.

___ The condensed water drain pipe has been correctly connected and led to the draining site.

___ The temperature of the water supplied by the external chiller is stable (5~15°C).

4.2 Power Supply

Power on the cooling unit and it will automatically enter standby mode. For the sake of safety, the fans will not automatically rotate. Only when it goes through manual mode, automatic mode, force mode or installation mode and returns to the standby mode, will the fans run at the minimum speed. After the display of the Delta trademark for six seconds, the LCD will enter the following status screen.



(Figure 4-1 : LCD status screen)

To know each screen's meaning and how to operate the control panel, please refer to **5.2 Control Panel Operation**.


4.3 Operating Temperature and Humidity

Use an auxiliary de-humidifier or air conditioner to adjust the indoor temperature and humidity until they fall within the operation scope.




WARNING:

If the indoor humidity is too high, the condensing effect around the coil may lead to too much condensed water, which could cause leakage or trigger an alarm.



(Figure 4-2A: HCH1850 Standard Operation Conditions)



(Figure 4-2B: HCH1870 Standard Operation Conditions)


If there is no auxiliary dehumidifier or air conditioner indoors, you may start the installation mode to reduce the humidity in the cabinet. See the following procedures:

- 1 In the status screen, press **↵** to enter into **Main Menu**, utilize **▲** and **▼** to select **Factory Setting** and press **↵**.
- 2 Enter **administer password**.
- 3 After entry, select the installation mode and press **↵** to confirm. Now, the fans will run at the minimum speed and the three-way ball valve will fully open and the bypass is closed. Press **ESC** for several times to return to the status screen and observe the change of temperature and humidity.
- 4 When the humidity falls within the operation scope, the **WARNING** indicator will flash and the buzzer will issue sustained short beeps for 0.5 second. The alarm will continue until you leave the installation mode.

4.4 Air Exhaust


You must carry out air exhaust procedures to get the air in the pipe naturally exhausted in accordance with the following procedures:

- 1 Fully open the shut-off valve and the bypass valve.



(Figure 4-3 : Fully open the shut-off valve and the bypass valve)

- 2 Rotate the outlet water pipe's manual exhaust valve counterclockwise.



(Figure 4-4 : Open the outlet water pipe's manual exhaust valve)

- 3 Open the water inlet end's user-supplied valve to let the water slowly flow into the pipe. After the water flows into the pipe, the air will be squeezed out.
- 4 After 6~7 seconds, when the air is exhausted and the water begins to be discharged from the pipe, turn off and lock the outlet water pipe's manual exhaust valve.




NOTE:

You must do the air exhaust procedures after any change in the pipeline structure. It is recommended to install an automatic exhaust valve for external piping. Refer to **3.7 External Piping**.

4.5 Water Leakage Detector


This cooling unit is provided with a water leakage detector at the cabinet bottom when delivered, which will be triggered to issue an alarm when in contact with water or liquid, reminding you to take proper measures. You must manually set the detector at the site for leakage detection, such as a low-lying place. If the lower piping is adopted, it is suggested to set it close to the pipeline below the raised floor.

Pass one end of the water leakage detector through the small hole at the lower part of the cabinet and set the detector at the above-mentioned place.



(Figure 4-5 : Water leakage detector installation)

4.6 Water Balance



(Figure 4-6 : Water balance)

The program adopts a compensation method and adjusts the flow rate with the first (most remote) cooling unit as a reference point. The process needs at least three people to work at the same time. It is suggested keeping communication by handheld walkie talkie. The number of the cooling units in a circuit varies and we take the six-unit configuration as an example. See the following procedures.

- 1 Set a balance valve at the return water end of the main pipe to adjust the total flow rate of the circuit.
- 2 Use the control panel to set all cooling units in the installation mode, (see **4.3 Operating Temperature and Humidity**) and the three-way ball valves will automatically fully open (100%).
- 3 Fully open the balance valve of the return water end and the branch balance valves at all branches and record the flow rate of each unit.
- 4 Adjust the balance valve of the return water end to 110% of the rated total flow rate. If the balance valve cannot reach this value when fully opened, keep it at full opening, and adjust the flow rate of each branch proportionally.
- 5 Fully open the branch balance valve of Unit 1, adjust the balance valve of the return water end of the main pipe circuit to enable Unit 1 to reach its rated flow rate ($\pm 5\%$). Make sure once again its branch balance valve is kept fully open.
- 6 Adjust the branch balance valve of Unit 2 to get it to reach the rated flow rate. Another person will observe the flow rate change of Unit 1, dynamically adjust the balance valve of the return water end and make up water to enable Unit 1 to reach the rated flow rate ($\pm 5\%$). After adjustment, record the opening of the branch balance valve of Unit 2.
- 7 Adjust the branch balance valve of Unit 3 to get it to reach the rated flow rate. Another person will observe the flow rate change of Unit 1, dynamically adjust the branch balance valve of Unit 1 and complement water to enable Unit 1 to reach the rated flow rate ($\pm 5\%$). After adjustment, record the opening of the branch balance valve of Unit 3.
- 8 Repeat the procedures 6 ~ 7 to adjust Units 4~6 and record the opening of the branch balance valves.
- 9 When all units are adjusted, record the opening of the balance valve of the return water end and the total flow rate (rated flow rate $\pm 10\%$).
- 10 If the circuit is unable to reach the rated value of the total flow rate after adjustment, please adjust the water flow of the chiller and water pump.

4.7 PID Setting

In light of different environmental conditions of data centers, the PID parameter values must be adjusted by qualified service personnel after installation so as to achieve the best cooling efficiency.

Please first read **5.2 Control Panel Operation** to get familiar with basic operation.

Path: **Main Menu** → **Setting** → **Controller**



(Figure 4-7 : Setting of PID Values)

- **Proportional constant (P)**

Adjust according to the error between the measured temperature and the set value.

- **Integration constant (I)**

Eliminate the error by adding or subtracting the integration coefficient by small incremental output.

- **Differential constant (D)**

Adjust the output according to the error change so as to correct the time-dependent correction rate.

The PID default values of the three-way ball valve are shown as follows:

P	I	D
9.00	0.55	0.000

- **Adjustment procedures**

The adjustment is made based on an open circuit method as follows:

- ① Keep the fans running at high speed (at least 70%) and observe the flow rates at the high, medium, and low openings of the three-way ball valve from the control panel.
- ② Adjust the three-way ball valve to the opening at half of the rated flow rate, which varies according to the pipeline configuration and pressure distribution at site. If the opening is too large (above 70%), reduce it to a medium opening (about 50%).
- ③ When the temperature and humidity of outlet air and return air are stable, record the

readings of time-dependent outlet air temperature and observe if the inlet and outlet water temperatures are stable.

- 4 Use the control panel to start the manual mode and increase the opening (above 75%). Due to the internal delay of the system, the outlet air temperature will change with the time.

- 5 Execute the Modbus Recorder program via the RS485 interface and calculate Td and τ values. The definition is as follows:

$$\tau = 1.5 \times (T_2 - T_1) \text{ [the time difference between 28.3\% (T}_1\text{) and 63.2\% (T}_2\text{) x 1.5]}$$

Td (Pseudo Dead Time) may be defined as $T_d = T_1 - \tau$

- 6 Calculate the best PID values in different modes in accordance with the following table.

Mode	Gain	Reset	Derivative
P	$\tau / (T_d \times G)$		
PI	$0.9 \tau / (T_d \times G)$	$0.3 / T_d$	
PID	$1.2 \tau / (T_d \times G)$	$0.5 / T_d$	$0.5 T_d$

* G (response gain): it varies with opening values and therefore, the medium opening or the opening at a medium flow rate is selected as the reference point.

* Reset and Derivative are defined: Reset=I/P, Derivative=D/P


- 7 The I and D values can be found from the Reset and Derivative values.
- 8 Enter the PID values found on the control panel, start the automatic mode, and make continuous observation of temperature oscillation. If the temperature is stable, record the value on a sheet of paper and output the adjusted set values (including supply air and return air temperature and humidity, fan speed, inlet water temperature, and outlet water temperature) via the SNMP interface.

• Operation trial

1. Confirm that the cooling unit is in automatic mode and observe if the supply and return air temperature and humidity, water flow rate, and water temperature are stable.
2. Change the set point, record the stability time (reaching the set point of supply air temperature) via the SNMP interface, and observe if there is instability and temperature oscillation.
3. Export the data and store them.

Chapter 5 : Operation

5.1 LCD Display Hierarchy



(Figure 5-1 : LCD display hierarchy)

5.2 Control Panel Operation



No.	Button	Description
1	ESC	Goes back to previous screen or cancels current operation.
2	↵	Enters your selected item or confirms your selection or setting.
3	▲	Goes back to previous screen, moves up or increases number.
4	▼	Goes to next screen, moves down or decreases number.

After entering a screen, if its options exceed four, you may press ▲▼ to turn the page. Press ↵, a highlighted zone appears and represents the current selected option, and press ▲▼ to move the highlighted zone.


To enter or change values (such as password or temperature), please use ▲▼. Press ↵ to skip to next field. In the last field, press ↵ to store and submit. Press ESC to cancel the current operation.


If it is kept in idle without operation, the display will automatically turn off and the backlight will go off.






NOTE: The default language of the control panel is English. The route for setting your preferred language is **Main Menu** → **Setting** → **Local Setting** → **Language** .


5.3 Status Screen and Main Menu



The LCD display will go off when the unit is idle. Press  to wake up the backlight and display the status screen. You may view the air supply status and the air flow percentage of the fans. The air flow percentage represents the fan speed and the more solid grids there are, the higher the fan speed.

In the status screen, press  to enter the **Main Menu** shown below.

If an alarm occurs, press   and you will see a screen display the description of the alarm.



- **Power ON/OFF**

Start up the cooling unit (automatic mode) or enter the standby mode.

- **Status**

View the system status, sensor readings, operation time and event records.

- **Setting (the user's password required)**


Adjust the set point, local setting, controller setting and alarm setting.

- **Administrator (the admin password required)**

Enter the manual mode and view the firmware version and system setting.

5.4 Account Authority and Login

The cooling unit has two accounts. **The administrator** has the highest authority and can alter all settings while **the user** can only alter the system setting.



When you try to enter **Setting** or **Administrator** screen, a password prompt will occur. If no operation is performed for a long time after login, the login status will become invalid after the system becomes idle. If you want to re-enter the above menu, you must re-enter the password.

In the password prompt screen, entering **the admin password** means the entry of administrator and entering **the user password** represents the entry of general users. If you only enter **Power ON/ OFF** or **Status** screen, no password is required.


The user's default password is **0000**.



NOTE: To avoid unauthorized change of and access to important settings, do not disclose the admin password. To get the admin password, contact service personnel.

5.5 Operation Modes


The cooling unit has five operation modes:

Operation mode	Description
Automatic mode	<p>Path : Main Menu → Power ON/ OFF → ON</p> <p>To get the cooling unit to automatically control its cooling capacity, please select the automatic mode and the system will automatically micro-adjust the fan speed and the opening of the three-way ball valve in accordance with the set points.</p> <p>You may also simultaneously press ▲▼ for three seconds in any screen to quickly switch between the automatic mode and the standby mode.</p> <p> NOTE: In the manual mode, the simultaneous pressing of ▲▼ for 3 sec will not make the unit automatically enter the automatic mode or standby mode.</p>
Standby mode	<p>Path: Main Menu → Power ON/ OFF → Standby</p> <p>In the standby mode, the fans run at the minimum speed, the three-way ball valve is fully closed and the chilled water goes through bypass without passing the coil.</p>
Manual mode	<p>Path: Main Menu → Administrator → Manual Mode</p> <p>The manual mode is used to test if the components work normally or make the system operate in accordance with the manual setting. In this mode, you may manually set: fan speed, ball valve opening, indicator on-off, backlight on-off, buzzer on-off, alarm dry contact on-off and chiller's water pump dry contact on-off.</p> <p>In the manual mode, press ESC to automatically return to the standby mode.</p>

Operation mode	Description
Installation mode	<p>Path: Main Menu → Administrator → System → Installation</p> <p>This mode is used to de-humidify and adjust the water balance. When it is started, the three-way ball valve will fully open and the fans will rotate at the minimum speed. When the system humidity falls within the operation scope, the WARNING indicator will flash and the buzzer will issue 0.5 sec short beeps continuously until you leave the installation mode.</p> <p>For the operating temperature and humidity, refer to 4.3 Operating Temperature and Humidity.</p>
Force mode	<p>Path: Main Menu → Setting → Controller</p> <p>The three-way ball valve is fully open and the fans run at the highest speed. This mode is generally used for unit testing or emergency cooling request.</p>

5.6 Shutdown

Path: **Main Menu** → **Power ON/ OFF** → **Standby**



WARNING:

In the standby mode, the unit is still in power-on status! In the standby mode, you must disconnect the input power to get the unit to fully power-off.



To shut down the cooling unit, you must first enable the standby mode. After selecting the standby mode, select **Y** and press **↵** to confirm. If the **STANDBY** indicator lights, the unit is in the standby mode. Now, the cooling unit is still in power-on status and the fans run at the minimum speed.

Next, disconnect the external power and make sure that the fans stop and the LCD display is off.

5.7 Setting of Cooling Unit

5.7.1 Local setting

Path: **Main Menu** → **Setting** → **Local Setting**



- **System time**

Use ▲▼ to set up the system time and press ⬅ to skip to the next field and finally press ⬅ to confirm.

- **ID (Number)**

Represent the number of the cooling unit connected in series and also the ID in the Modbus protocol. The default number is **1**. If several cooling units are connected in series, you must designate each unit with a different number.

- **Contrast**

Adjust the display screen contrast (0~5) and the default value is **2**.

- **Buzzer**

Set the buzzer on-off and issue an alarm beep to remind the user of an alarm event, if any. The default is **ON**.

- **Language**

Set the display language. Select a language and press ⬅ to confirm. The default is English (**EN**).

- **User PW**

To alter the current user's password , enter four digits.

- **Unit**

Set the temperature unit and the default is (°C).

- **Delay On**

The time difference between setting the startup of automatic mode and the actual operation. The cooling unit will start up in the seconds you have designated.

- **Baud rate**

Please set the on-line speed based on the Modbus protocol. The options include **9600**, **19200**, **38400** and **57600** and the default value is **9600**.

- **Total Alarm**

Decide what event can trigger the output dry contact 1. Please refer to the following descriptions:

1. All: Any alarm and fault event can trigger it.
2. Fault: Only fault events can trigger it.

Alarm events


- | | |
|--|--|
| 1. Filters are clogged | 5. High and low of chilled water flow |
| 2. Abnormal internal communication | 6. High and low of remote temperature and humidity |
| 3. High and low of air supply/ return temperature and humidity | 7. Overtime of maintenance |
| 4. High and low chilled water inlet/ outlet temperature | |

Fault events

- | | |
|--|--|
| 1. Emergency stop/ remote emergency stop | 7. Abnormal remote sensor |
| 2. Overflow of condensed water | 8. Abnormal chilled water inlet/ outlet temperature sensor |
| 3. Leakage alarm/ leakage open-circuit alarm | 9. Abnormal chilled water flow meter |
| 4. Fire | 10. Abnormal fan |
| 5. Smoke | 11. Abnormal three-way ball valve |
| 6. Abnormal air supply/ return temperature and humidity sensor | |

5.7.2 Set point

Path: **Main Menu** → **Setting** → **Set point**






- **Supply Air T (temperature)**

In the automatic mode, the cooling unit will automatically adjust the fans and three-way ball valve in accordance with this targeted supply air temperature.

5.7.3 Controller setting

Path: **Main Menu** → **Setting** → **Controller**



- **Force Mode**

When the force mode is enabled, the fans will run at full speed and the three-way ball valve will fully open, which is generally used for performance testing or at a high heat load.

If the **STANDBY** indicator on the control panel flashes, the unit is in the force mode.

Set the proportional constant, integral constant and derivative constant (**PID**). Refer to **4.7 PID Setting**.

- **Min Flow T**

When the return air temperature is lower than this value, the fans will run at the minimum speed to save energy and the default is **25°C**.

- **Max Flow T**

When the return air temperature is higher than this value, the fans will run at the maximum speed and the default is **40°C**.

- **Fan Step**

It is used to set the fan speed (range: 0~15) in the automatic mode. The default is 0 and the cooling unit will adjust the fan speed according to your setup.

- **Auto Recover**

When this function is enabled and the system is in the automatic mode before power-off, at a restart, the unit will directly return to the automatic mode.

- **Intelligent**


Display if the intelligent temperature control is enabled. This option only displays the status. You cannot change the setting. For change of setting, refer to **5.7.4 Setting of automatic control mode**.

- **Leak. Cut-Off**

If this function is enabled, the unit will automatically shut down once the water leakage detector detects leakage.

5.7.4 Setting of automatic control mode

Path: **Main Menu** → **Administrator** → **System** → **Intelligent**



This unit supports two kinds of automatic control modes:

1. Intelligent control (default)

The system will automatically adjust the fans and the actuator in accordance with the set supply air temperature.


2. PID control

The system will make adjustment by PID parameters.

When the unit enters the automatic mode, the default setting is intelligent control. If the intelligent control mode is off, the system will automatically adopt the PID control. To turn on or off the intelligent control, you need to key in **the admin password**.

5.7.5 Alarm setting

Path: **Main Menu** → **Setting** → **Set Alarm**





Set Sensor Alarm, Actuator Alarm and Out-of-Range Alarm. If an item display is ☐, this item is disabled. Press **←** at this item, use **▲▼** to select ☒, press **←** to confirm and the item is enabled.




NOTE: When an alarm event occurs in the manual mode, the indicator and buzzer will not act but the event will be stored in the event log.

- **Sensor alarm**

Path: **Main Menu** → **Setting** → **Set Alarm** → **Sensor Alarm**








Set the alarm on/ off for **Return Sensor**, **Supply Sensor**, **Remote Sensor 1-4**, **Water In/ Out Sensor**, **Flow Mater** and **Leak SEN** (leakage detector sensitivity).

- **Actuator alarm**



Path: **Main Menu** → **Setting** → **Set Alarm** → **Actuator**



Set the alarm on-off for **ball valve** and **fan 1~8**.

- **Out-of-Range alarm**



Path: **Main Menu** → **Setting** → **Set Alarm** → **Out Of Range**



The screens above only show parts of items. For whole items, please refer to the cooling unit's actual operation.

5.7.6 Inquiry of system status

Path: **Main Menu** → **Status** → **System**




Inquire about the system related information, including **cooling capacity**, **supply air temperature and humidity**, **return air temperature and humidity**, **remote 1 temperature and humidity**, **remote 2 temperature**, **remote 3 temperature**, **remote 4 temperature**, **chilled water inlet/ outlet temperature**, **chilled water flow rate**, **ball valve opening**, **ball valve command** (set the ball-valve opening), **fan command** (set the fan speed), **heater command**, **humidifier command**, **fan 1~8 failed**, **EPO active**, **fire active**, **smoke active**, **filter failed**, **drain pan full**, **leak active** (enable the leakage detection), and **wire leak open** (water leakage detector has open/ short issues).



NOTE: **Heater command** and **humidifier command** are reserved for HCHICB0 and HCH1DB0 models.

5.7.7 Inquiry/ elimination of event log

Path: **Main Menu** → **Status** → **Event Log**



In this screen, the number of current events/ total events is displayed and at most 3000 events can be recorded. Press ▲▼ to switch events. The events are numbered according to the occurrence time and the older the event, the smaller its number is. The digit in <> is the event code. If the records exceed 3000, older events will be over-written.

To clear any event log, the **admin password** is needed, and the route is **Main Menu → Administrator → System → Clear Log**.



NOTE:

The event log is important information for evaluating the system status and also a reference for service personnel to perform maintenance. Therefore, do not clear the event log without authorization.

5.7.8 Inquiry / reset of running hours


Path: **Main Menu → Status → Run Hours**

System	: 2000h	Fan 3	: 8000h
Filter	: 720h	Fan 4	: 8000h
Fan 1	: 8000h	Fan 5	: 8000h
Fan 2	: 8000h	Fan 6	: 8000h

Fan 7	: 8000h
Fan 8	: 8000h
Ball Valve	: 8000h

Inquire about the running hours of the system and components to assist you in evaluating the component status and judging the repair or replacement time.


The route for re-setting each component's operation time is **Main Menu → Administrator → System → Reset Component**.



After a component is changed, reset the operation time of **Filter**, **Fan 1-8** and **Ball valve**.

5.7.9 Change of system type


Path: **Main Menu** → **Administrator** → **System** → **Type**



Follow your data center's cold/ hot aisle configurations to set up system **Type** as **OPEN** or **CLOSE**.

5.7.10 Restoration of defaults

Path: **Main Menu** → **Administrator** → **System** → **Factory Setting**



Restore all factory defaults, including the set options and user and admin passwords.



WARNING: The restoration of factory defaults will reset the settings or parameters that have been changed! The cooling unit has selected different settings according to the different environment and random restoration may lead to system error. The restoration can be made only by qualified service personnel.

Chapter 6 : Maintenance and Cleaning

Periodic inspection and cleaning of the cooling unit can guarantee the equipment to operate at the best status.

The internal components such as fans and condensed water pan need periodic cleaning and inspection. This unit contains replaceable components and the cleaning and inspection of them can be done only by qualified service personnel.

6.1 Firmware Upgrade

For firmware upgrade, contact service personnel.

6.2 Storage

If you do not use this unit for long time, it is recommended that you wrap the unit using the original packing material and store it in a place with well controlled temperature and humidity (-15~65°C ; 0~95% RH, non-condensing) and free of corrosion substance, accumulated dust and pollutants. Do not place the unit horizontally or deposit things in or on the cabinet.



NOTE: For information and method of maintenance and cleaning, contact your local dealer or customer service. Do not perform maintenance if you are not trained for it.

Chapter 7 : Troubleshooting



WARNING:

The following troubleshooting actions can only be carried out by qualified service personnel. Unauthorized action may lead to major danger or equipment damage.

System Troubleshooting:

No.	Abnormal phenomenon	Possible cause	Elimination method
1	The fans cannot start.	The power supply is abnormal.	Make sure the input voltage is within the permissible range, the circuit breaker or switch is set at ON , and the cooling unit is correctly grounded.
		The fans are abnormal.	Make sure that each fan wiring is normal and change the abnormal fans if necessary.
2	The cooling unit cannot start.	The input voltage is abnormal.	Make sure the input voltage is within the permissible range, the circuit breaker or switch is set at ON , and the cooling unit is correctly grounded.
3	Forgot the password?	Forgot the user password or admin password?	Contact service personnel.
4	The operation noise is too high.	Foreign matter is attached to the fans or the fans' ball bearings are damaged.	Clean and inspect the fans.
		The fan speed is too high.	Check if the fans are running at full speed. Adjust the set point or the fan speed accordingly.
		There is foreign matter or impurity in the pipeline.	Inspect the Y-type filter of the external piping and clean it if necessary.
5	LCD display is abnormal and does not display.	The wiring is wrong.	Inspect if the wiring of the control panel is correct or re-start the cooling unit if necessary.
6	The alarm condition is satisfied but the buzzer does not beep.	The buzzer alarm function is not enabled.	Use the control panel to enable the buzzer alarm function. Path: Main Menu → Setting → Local Setting .

No.	Abnormal phenomenon	Possible cause	Elimination method
7	The set point cannot be reached.	The fans are old or abnormal.	Inspect the fans and change abnormal ones if necessary.
		The sensor detection is abnormal.	Inspect the sensors.
		The PID parameters are wrong.	Refer to 4.7 PID Setting .
		The heat load exceeds the cooling capacity.	Reduce the heat load or increase cooling units.
		The filters are clogged.	Replace or clean the filters.
		The coil is blocked.	Carry out the coil washing procedures.
		The chilled water flow rate is insufficient or its temperature is too high.	Inspect the flow rate and temperature of the chiller (5~15 degrees are ideal).
		The control module is wrong.	Repair or replace the control box.
		The actuator is abnormal.	Repair the actuator.
8	There is a water stain in the cabinet.	The humidity is too high.	Use an external de-humidifier to control the data center's humidity or enable the force mode to reduce the internal humidity of the data center.
		The inlet water temperature is too low.	Adjust the water supply temperature of the chiller (5-15 degrees are ideal).
		The fan speed is too low.	Adjust the fan speed.
		The drain pump is abnormal.	Confirm the functions of the drain pump are normal.
		The piping is abnormal.	Inspect if the chilled water pipeline and other pipelines are normal.
9	There is water leakage at the cabinet bottom.	The condensed water overflows.	Observe if the water level in the condensed water pan is too high, inspect the condensed water pump or make sure the condensed water pipe (without bending, damage or blockage) is correctly connected and the draining is normal. If upper piping with condensed water pump is adopted, the vertical lift shall not exceed five meters.

No.	Abnormal phenomenon	Possible cause	Elimination method
9	There is water leakage at the cabinet bottom.	The pipe system leaks.	Inspect and repair the leaking site.
		The cabinet is not on a leveled base.	Use the levelers to level the cabinet.
		The thermal insulating rubber layer of pipe is damaged.	Inspect and repair the damage site.
10	The EPO does not act.	The EPO wire goes off.	1) Inspect if the wiring is correct. 2) Contact service personnel to see if the EPO is set as Off (default: Off).
11	The signals of the remote sensors are abnormal.	The remote sensors are not correctly located.	Inspect each remote sensor's position.
12	The three-way ball valve has no response.	The actuator is not correctly connected.	Re-set the actuator.
13	It is unable to get on-line via the Modbus protocol.	The RS232 or RS485 connector is not correctly connected.	Re-connect the connector.
		The Baud rate setting is abnormal or the ID does not match.	Re-confirm the Baud rate and ID.

Alarm information on the LCD:

No.	Alarm Information	Possible cause	Elimination method
1	Filter Abnormal	The filters are clogged by foreign matter or are old.	Replace or clean the filters.
2	Drain Pan Full	The condensed water pipe or the condensed water pump is abnormal.	Remove the surplus water, inspect the condensed water pump or make sure the condensed water pipe (without bending, damage or blockage) is correctly connected and the draining is normal. If upper piping with condensed water pump is adopted, make sure the vertical lift does not exceed five meters.

No.	Alarm Information	Possible cause	Elimination method
3	EPO Active	The EPO button on the control panel is pressed or emergency stop is triggered due to fire or smoke.	Eliminate the abnormality, manually reset the unit by pressing the ▲ ▼ keys simultaneously for above 3 seconds and re-start the unit to recover the normal operation.
		Emergency stop is triggered due to leakage	1) Eliminate the abnormality, make sure the water leakage detector is dry, and press the ▲ ▼ keys simultaneously for above 3 seconds to recover the normal operation. 2) If the water leakage detector cannot be dried in a short time, go to Setting → Controller → Leak. Cut-Off to disable 'Leak. Cut-Off' function, and follow the actions mentioned in 1).
4	Leak Active	Leakage is detected.	Remove the surplus water and inspect the water level of the condensed water pan. Inspect if the drain function is normal and confirm that the condensed water pipe has no bending, damage or blockage. If upper piping with condensed water pump is adopted, the vertical life shall not exceed five meters.
5	Fire Active	Fire detection is triggered.	Inspect the environment and eliminate the abnormality.
6	Smoke Active	Smoke detection is triggered.	Inspect the environment and eliminate the abnormality.
7	Comm Abnormal	The CAN-Link port wiring is wrong or the unit ID is repeated.	Inspect the CAN-Link port wiring and confirm that the cooling units connected in series have independent and non-repeated IDs.
8	Return/ Supply Sensor	The air return/ supply sensor is abnormal or in bad contact.	Inspect the function of the air return/ supply sensor and confirm the wiring is stable.
9	Remote Sensor 1-4	The # remote sensor is abnormal or in bad contact.	Inspect the function of the # remote sensor and confirm the wiring is stable.
10	Water In Sensor	The chilled water inlet temperature sensor is abnormal or in bad contact.	Inspect the function of the chilled water inlet sensor and confirm the wiring is stable.
11	Water Out Sensor	The chilled water outlet temperature sensor is abnormal or in bad contact.	Inspect the function of the chilled water outlet sensor and confirm the wiring is stable.

No.	Alarm Information	Possible cause	Elimination method
12	Flow Meter	The flow meter is abnormal or in bad contact.	Inspect the function of the flow meter and confirm the wiring is stable.
13	Fan 1-8 Failed	The # fan is abnormal or in bad contact.	Inspect if the # fan is blocked or abnormal and confirm the connection wire is correctly connected.
14	Ball Valve Error	The three-way ball valve is abnormal.	Inspect if the three-way ball valve is in bad contact or faulty.
15	Return/ Supply/ Remote# T High	1) The environment temperature and humidity are abnormal. 2) The alarm setting is abnormal. 3) The temperature sensor is abnormal. 4) The load is too large.	1) Inspect if the environment temperature and humidity are within the operation scope. 2) Inspect if the out-of-range alarm setting is correct. 3) Inspect the temperature sensor function. 4) If the temperature is still too high after eliminating the above problems, please confirm the load does not exceed the cooling capacity of the cooling unit.
16	Return/ Supply/ Remote# T Low		
17	Return/ Supply/ Remote# RH High		
18	Return/ Supply/ Remote# RH Low		
19	Water In T High	1) The temperature or flow rate of the chilled water supplied by the chiller is abnormal. 2) The alarm setting is abnormal.	1) Inspect the temperature and flow rate of the chilled water. 2) Inspect if the out-of-range alarm setting is correct.
20	Water In T Low		
21	Water Flow High		
22	Water Flow Low		
23	Run Over Hours	The periodic maintenance has not been performed.	To guarantee the normal operation of the system, carry out the maintenance immediately.
24	Leak Wire Open	The water leakage detector is not correctly connected.	Inspect if the water leakage detector is loose, in bad contact or broken.
25	Remote EPO	The unit receives the remote system's message and shuts down.	Let the remote system send 'reset' command to the unit to recover normal operation.



NOTE: If the alarm still exists after the above possible causes are eliminated, please contact your dealer or customer service.

Appendix 1 : Technical Specifications

Model	HCH1850	HCH1870
Phase/ Frequency/ Input Voltage ***	1~, 50/60 Hz, 220V \pm 10%	1~, 50/60 Hz, 208-230V \pm 10% 1~, 50/60 Hz, 220-240V \pm 10%
Max. Power Consumption	1.05 kW	2.41 kW
Rated Cooling Capacity *	25.2 kW	43.4 kW
Max. Cooling Capacity **	29 kW	59.1 kW
Air Volume	4930m ³ /h	7500m ³ /h
Rated Chilled Water Flow Rate	68.3 LPM	80 LPM
Pressure Drop	110 kPa	98 kPa
Drain Pump (Optional)	Flow rate: 5 l/h; Rated vertical lift: 5m	
Display	HMI: LCD 64*128 pixels and four LED indicators.	
Max. Return Air Temperature	40 °C	50 °C
Max. Water Inlet Temperature	15 °C	15 °C
Operational Audible Noise	81.5 dBA @ 2900 CFM	88dB@4400CFM
Operating Temperature	4 ~ 40 °C	4 ~ 50 °C
	30~85% RH, non-condensing	
Storage Temperature	-15 ~ 65 °C (0 ~ 95% RH, non-condensing)	
Dimensions (Width x Depth x Height)	300 x 1090 x 2000 mm	300 x 1090 x 2000 mm
Net Weight	185 kg	187 kg



NOTE:

1. Refer to the rating label for the safety rating.
2. All specifications are subject to change without prior notice.

-
- * Testing conditions for rated cooling capacity:
HCH1850 return air temperature: 35°C DB/ 19.8°C WB/ chilled water inlet temperature degree: 7.2°C/ chilled water outlet temperature degree: 12.7°C.
HCH1870 return air temperature: 40.6°C DB/ 21.6°C WB/ chilled water inlet temperature degree: 7°C/ chilled water outlet temperature degree: 15.8°C.
- ** Testing conditions for the maximum cooling capacity:
HCH1850 return air temperature 40.6°C DB/ 21.6°C WB/ chilled water inlet temperature: 7.2°C/ chilled water outlet temperature: 13.8°C.
HCH1870 return air temperature 48.9°C DB/ 23.9°C WB/ chilled water inlet temperature: 7°C/ chilled water outlet temperature: 15.4°C.
- *** Model HCH1870 has two different input voltage values.


Appendix 2 : Periodic Inspection/ Maintenance List

Monthly Inspection/ Maintenance List

Date:

Model:

By:

Environment inspection	
The cooling unit is installed in?	_____
Is it free of dust and surplus moisture?	<input type="checkbox"/> Yes / <input type="checkbox"/> No
Is the cabinet appearance perfect without damage?	<input type="checkbox"/> Yes / <input type="checkbox"/> No
Record the supply air temperature	_____ degree (s)
Record the chilled water outlet temperature	_____ degree (s)
Record the supply air set point	_____ degree (s)
Can the cooling unit reach the set point?	<input type="checkbox"/> Yes / <input type="checkbox"/> No
Internal inspection	
Is there any impurity or foreign matter in the condensed water pan?	<input type="checkbox"/> Yes / <input type="checkbox"/> No
Do the filters function well?	<input type="checkbox"/> Yes / <input type="checkbox"/> Replacement or cleaning is needed
Does the water in the condensed water pipe flow smoothly?	<input type="checkbox"/> Yes / <input type="checkbox"/> No
Do the fans act normally and rotate without interference?	<input type="checkbox"/> Yes / <input type="checkbox"/> No
Does the drain pump act normally?	<input type="checkbox"/> Yes / <input type="checkbox"/> No
 Be sure to disconnect the input power before making the following inspections.	
Are the electronic joints stable and free of foreign matter?	<input type="checkbox"/> Yes / <input type="checkbox"/> No
Does the input power match the rated value of the cooling unit?	<input type="checkbox"/> Yes / <input type="checkbox"/> No
NOTE:	
Signature: _____	

Please copy this page for use during the inspection/ maintenance procedures.


Quarterly Inspection/ Maintenance List

Date:

Model:

By:

Cleaning: Clean the following components and use an air gun if necessary.

Filters (replace them if necessary)	<input type="checkbox"/> Completed / <input type="checkbox"/> Replaced
Front and rear doors and side panels	<input type="checkbox"/> Completed
 Be sure to disconnect the input power before cleaning the following components.	
Condensed water pan	<input type="checkbox"/> Completed
Condensed water pipe	<input type="checkbox"/> Completed
Fans	<input type="checkbox"/> Completed

General inspections

Is the water supplied by the chiller normal?	<input type="checkbox"/> Yes / <input type="checkbox"/> No
Does the alarm system operate normally?	<input type="checkbox"/> Yes / <input type="checkbox"/> No
Does the unit operate normally in all modes?	<input type="checkbox"/> Yes / <input type="checkbox"/> No

NOTE:

Signature: _____

Please copy this page for use during the inspection/ maintenance procedures.

Appendix 3 : Glycol Correction Table

Item	Glycol type	Adding proportion**					
		0%	10%	20%	30%	40%	50%
Cooling capacity *	Ethylene	1.00	0.96	0.89	0.81	0.73	0.65
Water-side pressure drop*		1.00	1.04	1.11	1.17	1.25	1.34



NOTE:

The correction parameters are based on the correction values under the following working conditions:

Return air temperature: 29.4°C DB/ 18.1°C WB; air volume: 4930m³/h; temperature difference of chilled water” 7.2°C; chilled water flow rate: 62LPM.

* Multiply the values read from the unit by the above parameters and the results are taken as the corrected cooling capacity and water-side pressure drop.

** The maximum brine adding proportion of the unit is 50%.

Appendix 4 : Warranty

Seller warrants this product, if used in accordance with all applicable instructions, to be free from original defects in material and workmanship within the warranty period. If the product has any failure problem within the warranty period, Seller will repair or replace the product at its sole discretion according to the failure situation.

This warranty does not apply to normal wear or to damage resulting from improper installation, operation, usage, maintenance or irresistible force (i.e. war, fire, natural disaster, etc.), and this warranty also expressly excludes all incidental and consequential damages.

Maintenance service for a fee is provided for any damage out of the warranty period. If any maintenance is required, please directly contact the supplier or Seller.

**WARNING!**

The individual user should take care to determine prior to use whether the environment and the load characteristic are suitable, adequate or safe for the installation and the usage of this product. The User Manual must be carefully followed. Seller makes no representation or warranty as to the suitability or fitness of this product for any specific application.

